

WINDOW FLASHING


Based on

AAMA Method “A-1”

Condition: The window is installed **after** the building paper is applied.

WINDOW FLASHING METHOD "A-1"

Step 1




Step #1

- Cut the building paper at a 45° angle to a point 9" up and 9" out from the upper corners of the rough opening.
- This will make a "flap" that will be used to cover the head flashing in Step #6.

WINDOW FLASHING METHOD "A-1"

Step 2




Step #2

- a. Install sill flashing extending 4" beyond the rough opening on each side.

WINDOW FLASHING METHOD "A-1"

Step 3




Step #3

- Apply a continuous bead of caulking on the back side of the window flange.
- Install the window according to the manufacturers specifications.

WINDOW FLASHING METHOD "A-1"

Step 4




Step #4

- Install jamb flashing over the window flange on each side.
- Extend the jamb flashing 4" above the rough opening and 8" below the rough opening.
- Do not let sill flashing extend beyond jamb flashing.

WINDOW FLASHING METHOD "A-1"

Step 5




Step #5

- Install head flashing over the window flange.
- Extend the head flashing 8" beyond the rough opening on each side.

WINDOW FLASHING METHOD "A-1"

Step 6




Step #6

- a. Allow the building paper "flap" to drape over the head flashing.

WINDOW FLASHING METHOD "A-1"

Step 7



Step #7

- a. Apply weather resistant tape over the 45° angle cut in the building paper.